




Reciprocating Compressor

BOCK® UL-HGX44e/UL-HGX56e

UL-HGX44e/475 ML 9
UL-HGX44e/565 ML 12
UL-HGX44e/665 ML 14
UL-HGX44e/770 ML 15

UL-HGX44e/475 S 12
UL-HGX44e/565 S 15
UL-HGX44e/665 S 20
UL-HGX44e/770 S 22

UL-HGX56e/850 ML 18
UL-HGX56e/995 ML 23
UL-HGX56e/1155 ML 28

UL-HGX56e/850 S 25
UL-HGX56e/995 S 30
UL-HGX56e/1155 S 35

Foreword

⚠ DANGER

Risk of accidents.

Refrigerating compressors are pressurized machines and as such call for heightened caution and care in handling.

Improper assembly and use of the compressor can result in serious or fatal injury!

- **To avoid serious injury or death, observe all safety instructions contained in these instructions before assembly and before using the compressor! This will avoid misunderstandings and prevent serious or fatal injury and damage!**
- **Never use the product improperly but only as recommended by this manual!**
- **Observe all product safety labels!**
- **Refer to local building codes for installation requirements!**

Unauthorized changes and modifications to the product not covered by this manual are prohibited and will void the warranty!

This instruction manual is a mandatory part of the product. It must be available to the personnel who operate and maintain this product. It must be passed onto the end customer along with the unit in which the compressor is installed.

This document is subject to the copyright of BOCK GmbH, Germany. The information provided in this manual is subject to change and improvements without notice.

Manufacturer and contact

Bock GmbH
Benzstr. 7
72636 Frickenhausen
Germany

Phone +49 7022 9454-0
Fax +49 7022 9454-137
bock.danfoss.com
bock.info@danfoss.com

Contents

Page

1	Safety	4
1.1	Identification of safety instructions	4
1.2	General safety instructions	4
1.3	Intended use	5
1.4	Qualifications required of personnel.....	5
2	Product description.....	6
2.1	Short description	6
2.2	Name plate (example)	7
2.3	Type key (example)	7
3	Areas of application	8
3.1	Refrigerants.....	8
3.2	Oil charge	8
3.3	Limits of application.....	9

4	Compressor assembly.....	10
4.1	Storage and transport.....	10
4.2	Setting up.....	10
4.3	Pipe connections.....	11
4.4	Pipes.....	11
4.5	Laying suction and pressure lines.....	11
4.6	Operating the shut-off valves.....	12
4.7	Operating mode of the lockable service connections.....	13
4.8	Suction pipe filter and filter drier.....	13
5	Electrical connection	14
5.1	General safety.....	14
5.2	Information for contactor and motor contactor selection.....	14
5.3	Standard motor design for direct or part winding start.....	14
5.4	Basic circuit diagramm for part winding start with standard motor.....	16
5.5	Special motor: design for direct or star-delta start.....	18
5.6	Basic circuit diagramm for star-delta start with special motor.....	20
5.7	Electronic trigger unit INT69 G.....	22
5.8	Connection of the trigger unit INT69 G.....	22
5.9	Function test of the trigger unit INT69 G.....	23
5.10	Oil sump heater (accessories).....	23
5.11	Capacity regulator (accessories).....	23
5.12	Selection and operation of compressors with frequency converters.....	24
6	Commissioning	24
6.1	Preparations for start-up.....	24
6.2	Pressure integrity test.....	24
6.3	Leak test.....	24
6.4	Evacuation.....	24
6.5	Refrigerant charge.....	25
6.6	Start-up.....	25
6.7	Avoiding slugging.....	25
6.8	Connection of oil level regulator.....	26
7	Maintenance	27
7.1	Preparation.....	27
7.2	Work to be carried out.....	27
7.3	Condensat drainage.....	27
7.4	Spare parts recommendation/accessories.....	27
7.5	Lubricants / oils.....	27
7.6	Decommissioning.....	27
8	Accessories.....	28
8.1	Capacity regulator.....	28
9	Technical data.....	30
10	Dimensions and connections	32
11	Declaration of incorporation.....	34
12	UL-Certificate of Compliance.....	36
13	Service	37

1| Safety

1.1 Identification of safety instructions



Indicates a dangerous situation which, if not avoided, will cause immediate fatal or serious injury.



Indicates a dangerous situation which, if not avoided, may cause fatal or serious injury.



Indicates a dangerous situation which, if not avoided, may cause fairly severe or minor injury.



Indicates a situation which, if not avoided, may cause property damage.



Important information or tips on simplifying work.

US

1.2 General safety instructions



Risk of accidents.

Refrigerating compressors are pressurized machines and as such call for heightened caution and care in handling.

The maximum permissible overpressure must not be exceeded, even for testing purposes!

Risk of burns!

- Depending on the operating conditions, surface temperatures of over 140 °F (60 °C) on the discharge side or below 32 °F (0 °C) on the suction side can be reached.

- Contact with refrigerant must be avoided.

Contact with refrigerant can cause severe burns and skin damage.

1| Safety

1.3 Intended use

⚠ WARNING

The compressor may not be used in potentially explosive environments!

- These assembly instructions describe the standard version of the compressor named in the title manufactured by Bock. Bock refrigerating compressors are intended for installation in a machine (within the EU according to the EU Directives 2006/42/EC Machinery Directive, 2014/68/EU Pressure Equipment Directive, outside the EU according to the respective national regulations and guidelines).

Commissioning is permissible only if the compressor has been installed in accordance with these assembly instructions and the entire system into which it is integrated has been inspected and approved in accordance with legal regulations.

The compressors are intended for use in refrigeration systems in compliance with the limits of application.

Only the refrigerant specified in these instructions may be used.

Any other use of the compressor is prohibited!

1.4 Qualifications required of personnel

⚠ WARNING

Inadequately qualified personnel poses the risk of accidents, the consequence being serious or fatal injury. Work on compressors is therefore reserved for personnel who are qualified to work on pressurized refrigerant systems:



- For example, a refrigeration technician, refrigeration mechatronic engineer. As well as professions with comparable training that enables personnel to assemble, install, maintain and repair refrigeration and air-conditioning systems. Personnel must be capable of assessing the work to be carried out and recognizing any potential dangers.

US

2 | Product description

2.1 Short description

- **UL-HGX44e:** Semi-hermetic four-cylinder reciprocating compressor with suction-gas cooled drive motor.
- **UL-HGX56e:** Semi-hermetic six-cylinder reciprocating compressor with suction-gas cooled drive motor.
- Preferred application range: normal refrigerating and air-conditioning.
- The stream of refrigerant sucked out of the evaporator flows over the motor and cools it intensively. In this way, the motor can be kept at a relatively low temperature level, particularly under high loads.



Dimension and connection values can be found in Chapter 9.

2| Product description

2.2 Name plate (example)

BOCK		Bock GmbH, Benzstr. 7 72636 Frickenhausen, Germany		c  us 	
				thermally protected system	
1	Type	: UL-HGX44e/770 S 22	380-420 Y/YY	-3-	50HZ
2	No	: BB12345A001	n	: 1450 min ⁻¹	V _{th} : 2365 cfh
3	I _{max}	: 35,0 A	440-480 Y/YY	-3-	60HZ
4	I _{block}	Y: 101 A YY: 174 A	n	: 1740 min ⁻¹	V _{th} : 2838 cfh
5	P _{max}	: LP/HP = 276/406 psig	IP 65	Oil: BOCK lub E55	

Fig. 3

1	Type designation	6	Voltage, circuit, frequency
2	Machine number	7	Nominal rotation speed
3	maximum operating current	8	Displacement
4	Starting current (rotor blocked)	9	Voltage, circuit, frequency
	Y: Part winding 1	10	Nominal rotation speed
	YY: Part windings 1 and 2	11	Displacement
5	LP: Max. admissible operating pressure (g) Low pressure side	12	Oil type filled at the factory
	HP: Max. admissible operating pressure (g) High pressure side	13	Terminal box protection type

 **Observe the limits of application diagrams!**

 **Electrical accessories can change the IP protection class!**

US

2.3 Type key (example)

UL-HG X 44 e / 770 S 22

UL	HG	X	44	e	/	770	S	22	
									Engine performance in HP
									Motor variant ³⁾
									Swept volume
									e-series
									Numbers of cylinders
									Size
									Oil filling ²⁾
									Series ¹⁾
									Identification UL compressor

1) HG - Hermetic Gas-Cooled (suction gas-cooled)

2) X - Ester oil charge

3) S - More powerful motor

ML - Motor for normal cooling and deep freezing

3 | Areas of application

3.1 Refrigerants

HFC + blends	R134a, R404A/R507, R407F
HFC/HFO blends	R448A, R449A, R450A, R452A, R513A

More informations about approved refrigerants on Bock compressor selection tool VAP (vap.bock.de).

3.2 Oil charge


- The compressors are filled at the factory with the following oil type: **BOCK**lub E55



For refilling, we recommend the above oil types.
Alternatives: see chapter 7.4

NOTICE

The oil level must be in the visible part of the sight glass; damage to the compressor is possible if overfilled or under-filled!



3 | Areas of application

3.3 Limits of application

NOTICE

Compressor operation is possible within the operating limits. These can be found in Bock compressor selection tool (VAP) under vap.bock.de. Observe the information given there.

- Permissible ambient temperature: -4 °F...140 °F (-20 °C...+60 °C).
- Max. permissible discharge end temperature 284 °F (140 °C).
- Max. permissible switching frequency 12x /h.
- A minimum running time of 3 min. steady-state condition (continuous operation) must be achieved.

For operation with supplementary cooling:

- Use only oils with high thermal stability.
- Avoid continuous operation near the threshold.
- The suction gas superheat temperature may need to be reduced or set individually when operating near to the threshold.

For operation with capacity regulator:

- Continuous operation, when the capacity regulator is activated, is not permissible and can cause damage to the compressor.
- The suction gas superheat temperature may need to be reduced or set individually when operating near to the threshold.
- When the capacity regulator is activated, the gas velocity in the system can not under certain circumstances ensure that sufficient oil is transported back to the compressor.

For operation with frequency converter:

- The maximum current and power consumption must not be exceeded. In the case of operation above the mains frequency, the application limit can therefore be limited.

When operating in the vacuum range, there is a danger of air entering on the suction side. This can cause chemical reactions, a pressure rise in the condenser and an elevated compressed-gas temperature. Prevent the ingress of air at all costs!

**Maximum admissible operating pressure (LP/HP)¹⁾:
276/406 psig (19/28 bar)**

¹⁾ LP = Low pressure
HP = High pressure

US

4 | Compressor assembly



New compressors are factory-filled with inert gas. Leave this service charge in the compressor for as long as possible and prevent the ingress of air. Check the compressor for transport damage before starting any work.

4.1 Storage and transport



- Storage at -22 °F...+158 °F, (-30 °C...+70 °C), maximum permissible relative humidity 10 % - 95 %, no condensation
- Do not store in a corrosive, dusty, vaporous atmosphere or in a combustible environment.




- Use transport eyelet.
- Do not lift manually!
- Use lifting gear!

4.2 Setting up




ATTENTION Attachments (e.g. pipe holders, additional units, fastening parts, etc.) directly to the compressor are not permissible!



- Provide adequate clearance for maintenance work.
- Ensure adequate compressor ventilation.



- Do not use in a corrosive, dusty, damp atmosphere or a combustible environment.



- Setup on an even surface or frame with sufficient load-bearing capacity.
- Single compressor preferably on vibration damper.
- Duplex and parallel circuits always rigid.



- Sun protection: If the compressor is set up outdoors, it has to be protected from direct sunlight.

4 | Compressor assembly

4.3 Pipe connections

NOTICE

Damage possible.

Do not solder as long as the compressor is under pressure. Superheating can damage the valve. Remove the pipe supports therefore from the valve for soldering and accordingly cool the valve body during and after soldering.

Only solder using inert gas to inhibit oxidation products (scale).




Fig. 5: graduated internal diameter

- The **pipe connections** have graduated inside diameters so that pipes with standart millimetre and inch dimensions can be used.
- The connection diameters of the shut-off valves are rated for maximum compressor output. **The actual required pipe cross section must be matched to the output. The same applies for non-return valves.**

4.4 Pipes

- Pipes and system components must be clean and dry inside and free of scale, swarf and layers of rust and phosphate. Only use air-tight parts.
- When using drawing oils in the inner pipe, the oils must then be completely removed by degreasing.
- Lay pipes correctly. Suitable vibration compensators must be provided to prevent pipes being cracked and broken by severe vibrations.
- Ensure a proper oil return.
- Keep pressure losses to an absolute minimum.

US

4.5 Laying suction and pressure lines

NOTICE


Improperly installed pipes can cause cracks and tears, the result being a loss of refrigerant.



Proper layout of the suction and discharge lines directly after the compressor is integral to the system's smooth running and vibration behavior.

4 | Compressor assembly

A rule of thumb: Always lay the first pipe section starting from the shut-off valve **downwards and parallel to the drive shaft**.



US

a) For HG44e an intermediate flange (height 27 mm) is optional available, Art-Nr. 81194.

With this intermediate flange it is possible to lay the pressure line directly from the valve to the left or right.



4.6 Operating the shut-off valves

- Before opening or closing the shut-off valve, release the valve spindle seal by approx. $\frac{1}{4}$ of a turn counter-clockwise.
- After activating the shut-off valve, re-tighten the adjustable valve spindle seal clockwise.




Fig. 7




Fig. 8

4 | Compressor assembly

4.7 Operating mode of the lockable service connections




Fig. 9

Opening the shut-off valve:

Spindle: turn to the left (counter-clockwise) as far as it will go.

—> Shut-off valve completely opened / service connection closed.

The connection which cannot be shut off is intended for safety devices.




Fig. 10

Opening the service connection

Spindle: Turn $\frac{1}{2}$ - 1 turn to the right clockwise.

—> Service connection opened / shut-off valve opened.

The connection which cannot be shut off is intended for safety devices.

US

After activating the spindle, generally fit the spindle protection cap again and tighten with 14-16 Nm. This serves as a second sealing feature during operation.

4.8 Suction pipe filter and filter drier

For systems with long pipes and higher degree of contamination, a filter on the suction-side is recommended. The filter has to be renewed depending on the degree of contamination (reduced pressure loss).

Moisture in the refrigeration circuit can lead to crystal and hydrate formation. For this reason, we recommend using a filter drier and a sight glass with a moisture indicator.

5 | Electrical connection

5.1 General safety

⚠ DANGER

Risk of electric shock! High voltage!
Only carry out work when the electrical system is disconnected from the power supply!

NOTICE

When attaching accessories with an electrical cable, a minimum bending radius of 3 x the cable diameter must be maintained for laying the cable.



Connect the compressor motor in accordance with the circuit diagram (see inside of terminal box).

- Use suitable cable entry point of the correct protection type (see name plate) for routing cables into the terminal box. Insert the strain relieves and prevent chafe marks on the cables.
- Compare the voltage and frequency values with the data for the mains power supply.

Only connect the motor if these values are the same.

US

5.2 Information for contactor and motor contactor selection

All protection equipment, switching and monitoring devices must comply with the local safety regulations and established specifications (e.g. VDE) and regulations as well as the manufacturer's specifications. **Motor protection switches are required!** Motor contactors, feed lines, fuses and motor protection switches must be rated according to the maximum operating current (see name plate). For motor protection, use a current-independent, time-delayed overload protection device for monitoring all three phases. Adjust the overload protection device so that it must be actuated within 2 hours at 1.2 times the maximum working current.

5.3 Standard motor, design for direct or part winding start

Designation on the name plate
Y/YY





Compressors with this marking are suitable for direct or partial winding start. The motor winding is subdivided into two parts: **Part winding 1 = 50 % and part winding 2 = 50 %**. This winding division reduces the start-up current needed for a part winding start to approx. 50 % of that for a direct start.



A mechanical unloaded start with bypass solenoid valve is not required.

5 | Electrical connection

The motor is wired for direct start (YY) at the factory. For part winding start Y / YY, the bridges must be removed and the motor feed line connected according to the circuit diagram:

400 V	
Direct start YY	Part winding start Y/YY
	
	

US



INFO

The supplied insulators must be mounted according to the illustrations as shown.

The connection examples shown refer to the standard version. In the case of special voltages, the instructions affixed to the terminal box apply.

Only direct start is possible with LSPM Motor.

NOTICE

Failure to do this results in opposed rotary fields and results in damage to the motor. After the motor starts up via partial winding 1, partial winding 2 must be switched on after a maximum delay of one second. Failure to comply can adversely affect the service life of the motor.

5.4 Basic circuit diagram for part winding start with standard motor





Fig. 11

BP2	High pressure safety monitor
BP3	Safety chain (high/low pressure monitoring)
BT1	Cold conductor (PTC sensor) motor winding
BT2	Thermal protection thermostat (PTC sensor)
BT3	Oil temperature sensor
BT4	Release switch (thermostat)
DELTA-P II	Oil differential pressure sensor DELTA-P II (accessorie)
EB1	Oil sump heater
EC1	Compressor motor



US

FC1.1/1.2	Motor protection switch
FC2	Control power circuit fuse
INT69 G	Electronic trigger unit INT69 G
KF1	Delay relay for contactor switchover
QA1	Main switch
QA2	Mains contactor (part winding 1)
QA3	Mains contactor (part winding 2)
SF1	Control voltage switch

5 | Electrical connection

5.5 Special motor: design for direct or star-delta start







A mechanical unloaded start with bypass solenoid valve is required for the star-delta start.

Designation on the name plate
Δ / Y

US

5 | Electrical connection

Star-delta start-up is only possible for 230 V power supply. Example:

230 V Δ		400 V Y
Direct start	Star-delta start	Direct start only
		
 Insulator	 Insulators	 Insulators



INFO


The supplied insulators must be mounted according to the illustrations as shown.

The connection examples shown refer to the standard version. In the case of special voltages, the instructions affixed to the terminal box apply.


Only direct start is possible with LSPM Motor.

US

5.6 Basic circuit diagram for star-delta start with special motor



BP2	High pressure safety monitor
BP3	Safety chain (high/low pressure monitoring)
BT1	Cold conductor (PTC sensor) motor winding
BT2	Thermal protection thermostat (PTC sensor)
BT3	Oil temperature sensor
BT4	Release switch (thermostat)
DELTA PII	Oil differential pressure sensor DELTA-P II (accessorie)
EB1	Oil sump heater
EC1	Compressor motor



US

FC1.1/1.2	Motor protection switch
FC2	Control power circuit fuse
INT69 G	Electronic trigger unit INT69 G
KF1	Delay relay for contactor switchover
QA1	Main switch
QA2	Mains contactor
QA3	Δ-contactor
QA4	Y-contactor
SF1	Control voltage switch

5 | Electrical connection

5.7 Electronic trigger unit INT69 G

The compressor motor is fitted with cold conductor temperature sensors (PTC) connected to the electronic trigger unit INT69 G in the terminal box. In case of excess temperature in the motor winding, the INT69 G deactivates the motor contactor. Once cooled, it can be restarted only if the electronic lock of the output relay (terminals B1+B2) is released by interrupting the supply voltage.

The hot gas side of the compressor can also be protected against overtemperature using thermal protection thermostats (accessory).

The unit trips when an overload or inadmissible operating conditions occur. Find and remedy the cause.



The relay switching output is executed as a floating changeover contact. This electrical circuit operates according to the quiescent current principle, i.e. the relay drops into a the idle position and deactivates the motor contactor even in case of a sensor break or open circuit.

5.8 Connection of the trigger unit INT69 G



Connect the trigger unit INT69 G in accordance with the circuit diagram. Protect the trigger unit with a delayed-action fuse (FC2) of max. 4 A. In order to guarantee the protection function, install the trigger unit as the first element in the control power circuit.

NOTICE

Measure circuit BT1 and BT2 (PTC sensor) must not come into contact with external voltage. This would destroy the trigger unit INT69 G and PTC sensors.




Fig. 13
Terminal box

5 | Electrical connection

5.9 Function test of the trigger unit INT69 G

Before commissioning, after troubleshooting or making changes to the control power circuit, check the functionality of the trigger unit. Perform this check using a continuity tester or gauge.

Gage state	Relay position
Deactivated state	11-12
INT69 G switch-on	11-14
Remove PTC connector	11-12
Insert PTC connector	11-12
Reset after mains on	11-14

Relay position INT69 G




Fig. 14


5.10 Oil sump heater (accessories)

When the compressor is at a standstill, refrigerant diffuses into the lubricating oil of the compressors housing, depending on pressure and ambient temperature. This reduces the lubricating capacity of the oil. When the compressor starts up, the refrigerant contained in the oil evaporates out through the reduction in pressure. The consequences can be foaming and migration of the oil, causing oil shocks under certain circumstances.

Operation: The oil sump heater operates when the compressor is at a standstill. When the compressor starts up, the oil sump heater switches off again automatically.

Connection: The oil sump heater must be connected via an auxiliary contact (or parallel wired auxiliary contact) of the compressor contactor to a separate electric circuit.

El. data: 230 V AC - 1 - 60 Hz, 160 W.



NOTICE

Connection to the current path of the safety control chain is not permitted.

Fig. 15

5.11 Capacity regulator (accessories)

NOTICE

A fuse (max. 3xIB in accordance with IEC 60127-2-1) corresponding to the rated current must be placed in front of every magnetic coil of the capacity regulator as short-circuit protection. The rated voltage of the fuse must be equal to or greater than the rated voltage of the magnetic coil. The ability of the fuses to switch off must be greater than or equal to the maximum assumable short-circuit current at the installation location.

5 | Electrical connection

5.12 Selection and operation of compressors with frequency converters

For safe operation of the compressor, the frequency converter must be able to apply an overload of at least 140 % of the compressor's maximum current (I-max.) for at least 3 seconds.

When using frequency converters, the following things must also be observed:

- 1. The maximum permissible operating current of the compressor (I-max) (see type plate or technical data) must not be exceeded.
- 2. If abnormal vibrations occur in the system, the affected frequency ranges in the frequency converter must be blanked out accordingly.
- 3. The maximum output current of the frequency converter must be greater than the maximum current of the compressor (I-max).
- 4. After each compressor start, run for at least 1 minute at a frequency of at least 50 Hz.
- 5. Carry out all designs and installations in accordance with the local safety regulations and common rules (e.g. VDE) and regulations as well as in accordance with the specifications of the frequency converter manufacturer.

Rotational speed range	0 - f-min	f-min - f-max
Start-up time	< 1 s	ca. 4 s
Switch-off time	immediately	

f-min/f-max see chapter 9: Technical data: permissible frequency range

6 | Commissioning

6.1 Preparations for start-up



To protect the compressor against inadmissible operating conditions, high pressure and low pressure pressostats are mandatory on the installation side.

The compressor has undergone trials in the factory and all functions have been tested. There are therefore no special running-in instructions.

Check the compressor for transport damage!

6.2 Pressure integrity test

The compressor has been tested in the factory for pressure integrity. If however the entire system is to be subjected to a pressure integrity test, this should be carried out in accordance with EN 378-2 or a corresponding safety standard **without the inclusion of the compressor.**

6 | Commissioning

6.3 Leak test

⚠ DANGER

Risk of bursting!

The compressor must only be pressurized using nitrogen (N₂). Never pressurize with oxygen or other gases!

The maximum permissible overpressure of the compressor must not be exceeded at any time during the testing process (see name plate data)! Do not mix any refrigerant with the nitrogen as this could cause the ignition limit to shift into the critical range.

- Carry out the leak test on the refrigerating plant in accordance with UL 207 or a corresponding safety standard, while always observing the maximum permissible overpressure for the compressor.

6.4 Evacuation

NOTICE

Do not start the compressor if it is under vacuum. Do not apply any voltage - even for test purposes (must only be operated with refrigerant).

Under vacuum, the spark-over and creepage current distances of the terminal board connection bolts shorten; this can result in winding and terminal board damage.

US

- First evacuate the **system** and then include **the compressor in the evacuation process**.
- Relieve the compressor pressure.
- Open the suction and pressure line shut-off valves.
- Evacuate the suction and discharge pressure sides using the vacuum pump.
- At the end of the evacuation process, the vacuum should be < 0.02 psig (1.5 mbar) when the pump is switched off.
- Repeat this process as often as is required.

6.5 Refrigerant charge

⚠ CAUTION

Wear personal protective clothing such as goggles and protective gloves!

- Make sure that the suction and pressure line shut-off valves are open.
- With the compressor switched off, add the liquid refrigerant directly to the condenser or receiver, breaking the vacuum.
- If the refrigerant needs topping up after starting the compressor, it can be topped up in vapor form on the suction side, or, taking suitable precautions, also in liquid form at the inlet to the evaporator.

NOTICE

- **Avoid overfilling the system with refrigerant!**
- **To avoid shifts in concentration, zeotropic refrigerant blends must always only be filled into the refrigerating plant in liquid form.**
- **Do not pour liquid refrigerant through the suction line valve on the compressor.**
- **It is not permissible to mix additives with the oil and refrigerant.**

6 | Commissioning

6.6 Start-up

⚠ WARNING

Ensure that both shut-off valves are open before starting the compressor!

- Check that the safety and protection devices (pressure switch, motor protection, electrical contact protection measures, etc.) are all functioning properly.
- Switch on the compressor and let it run for at least 1 minute at a frequency of at least 50 Hz. Only then may the speed of the compressor be reduced.
- **Check the oil level by:** The oil must be visible in the sight glass.

NOTICE

**If larger quantities of oil have to be topped up, there is a risk of oil hammer effects.
If this is the case check the oil return!**

6.7 Avoiding slugging

NOTICE

Slugging can damage the compressor and cause refrigerant to leak.

To prevent slugging:

- The complete refrigeration system must be properly designed.
- All components must be compatibly rated with each other with regard to output (particularly the evaporator and expansion valves).
- Suction gas superheat at the compressor input **should be min. 7 - 10 K.** (check the setting of the expansion valve).
- The system must reach a state of equilibrium.
- Particularly in critical systems (e.g. several evaporator points), measures are recommended such as replacement of liquid traps, solenoid valve in the liquid line, etc.

There should be no movement of refrigerant whatsoever while the compressor is at a standstill.

The use of a check valve is strongly recommended, especially for heat pump applications. Otherwise there is a risk of back condensation, which can cause compressor damage.

6.8 Connection of oil level regulator

Oil level regulation systems have proven themselves with parallel circuits of several compressors. The connection "O" is provided for installing an oil level regulator (see dimensions drawing). All common oil level regulators from AC&R, ESK and Carly as well as the OM3 TraxOil oil level regulation system from Alco can be connected directly without adapters (see Fig. 16). A sight glass on the oil level regulator is not required.





Fig. 16

Mechanical oil level regulator
at the "O" connection



7 | Maintenance

7.1 Preparation

⚠ WARNING

Before starting any work on the compressor:

- Switch off the compressor and secure it to prevent a restart.
- Relieve compressor of system pressure.
- Prevent air from infiltrating the system!

After maintenance has been performed:

- Connect safety switch.
- Evacuate compressor.
- Release switch lock.

7.2 Work to be carried out

In order to guarantee optimum operational reliability and service life of the compressor, **we recommend** carrying out servicing and inspection work at regular intervals:

• Oil change:

- not mandatory for factory-produced series systems.
- for field installations or when operating near the application limit: for the first time after 100 to 200 operating hours, then approx. every 3 years or 10,000 - 12,000 operating hours. Dispose of used oil according to the regulations; observe national regulations.


- **Annual checks:** Oil level, leak tightness, running noises, pressures, temperatures, function of auxiliary devices such as oil sump heater, pressure switch.

7.3 Condensate drainage

The terminal box has the option for Condensate drainage (see Fig. 17).



ATTENTION When the condensate drain is used, the protection rating of the terminal box is reduced from IP65 to IP32!



Condensate drainage

Fig. 17

7.4 Spare parts recommendation/accessories

Available spare parts and accessories can be found on our compressor selection tool under vap.bock.de as well as at bockshop.bock.de.

Only use genuine Bock spare parts!

7.5 Lubricants / oil

The oil type filled as standard in the factory is marked on the **name plate**, and this should always be used, even in the case of maintenance units. **Alternative oil types** can vary significantly in quality due to additives or inferior raw materials by the manufacturer. Validation within the compressors entire operating limits can not be guaranteed, if such alternative oil types are used. It is for this reason, that we only recommend the use of oil from Bock! Bock assumes no liability for any damage arising from alternative oil types.

Bock standard oil type: BOCKlub E55

7.6 Decommissioning

Close the shut-off valves on the compressor. Drain the refrigerant (it must not be discharged into the environment) and dispose of it according to the regulations. When the compressor is depressurised, undo the fastening screws of the shut-off valves. Remove the compressor using an appropriate hoist. Dispose of the oil inside in accordance with the applicable national regulations.

8 | Accessories

8.1 Capacity regulator

NOTICE

If the capacity regulator is installed at the factory, it is subsequently installed and connected by the customer.





Fig. 18



HG56e




Fig. 19

Delivery condition 1 (from the factory):
Cylinder cover prepared for capacity regulator.




Fig. 21

Delivery condition 2 (from the factory):
Connect capacity regulator in terminal box or
switch cabinet.




Fig. 20

Before commissioning, the blind flange with
screws must be removed and replaced by the
new set capacity regulator with O-ring joints
and screws. Observe position and construction
of the capacity regulator.

**Attention! Compressor is under pressure!
Depressurize the compressor first.**

⚠ WARNING

Several capacity regulators cannot switch at the same time during compressor operation! Otherwise the sudden change in load can damage the compressor! Comply with the switching interval of 60s.

- Comply with the switching sequence:
 Switching on LR1 — 60s —> LR2
 Switching off LR2 — 60s —> LR1

NOTICE

- **Capacity-regulated operation alters the gas speeds and pressure ratios of the refrigerating plant: Adjust the suction line routing and dimensioning accordingly, do not set the control intervals too close and do not let the system switch more than 12 times per hour (refrigerating plant must have reached a state of equilibrium). Continuous operation in the control stage is not recommended as the gas velocity in the plant system under certain circumstances does not guarantee sufficient oil return to the compressor with activated capacity regulator.**

We recommend switching to unregulated operation (100 % capacity) for at least 5 minutes per capacity-regulated operating hour. An assured oil return can also be realised by a 100 % capacity requirement after each compressor restart.

- **Electrical actuation of the solenoid valve: Normally open, (corresponds to 100 % compressor capacity).**
- **For digital capacity regulation see document 09900.**

US

Special accessories are only premounted in the factory if ordered specially by customer. Retrofitting is possible in full compliance with the safety instructions and repair instructions enclosed with the kits. Information about the use, operation, maintenance and servicing of the components is available in the printed literature or on the internet under www.bock.de.

For the capacity regulator a step protection is optional available, Art-Nr. 81449.




Fig. 22

9 | Technical data

Type	No. of cylinders	Displacement (1450 / 1740 rpm)	Electrical data ③				Weight	Connections ④	Oil charge (ex works)	Oil charge (sight glass center)
			Voltage ①	Max. operating current ②	Max. power consumption ②	Starting current (rotor locked)				
		50 Hz 60 Hz		PW 1+2		PW 1 / PW 1+2	kg		ltr (fl.oz)	ltr (fl.oz)
		cfh	V	A	kW (HP)	A	Hz	mm (inch)	mm (inch)	
475 ML 9	4	1460 1752	380-420 V Y/YY - 3 - 50 Hz PW 440-480 V Y/YY - 3 - 60 Hz PW PW = Part Winding Winding ratio : 50 % / 50 %	19	13.3 (18,1)	65 / 109	25 - 70	35 (1 3/8)	28 (1 1/8)	2.3 (81)
475 S 12		1460 1752		23	15.9 (21,6)	87 / 149				2.7 (95)
565 ML 12		1737 2085		22	16.0 (21,8)	65 / 109				
565 S 15		1737 2085		26	18.8 (25,6)	101 / 174				
665 ML 14		2039 2447		26	18.6 (25,3)	87 / 149				
665 S 20		2039 2447		30	22.2 (30,2)	101 / 174				
770 ML 15		2365 2838		30	21.5 (29,2)	101 / 174		42 (1 5/8)		
770 S 22		2365 2838		35	25.9 (35,2)	101 / 174				

① Tolerance (± 10%) relative to the mean value of the voltage range.

Other voltages and types of current on request.

② - The specifications for max. power consumption apply for 60Hz operation.

- Take account of the max. operating current / max. power consumption for design of fuses, supply lines and safety devices. Fuse: Consumption category AC3

③ All specifications are based on the average of the voltage range

④ For solder connections

US

① Tolerance ($\pm$ 10%) relative to the mean value of the voltage range.
Other voltages and types of current on request.

- The specifications for max. power consumption apply for 60Hz operation.
- Take account of the max. operating current / max. power consumption for design of fuses, supply lines and safety devices.


Fuse: Consumption category AC3

③ All specifications are based on the average of the voltage range

④ For solder connections

10 | Dimensions and connections



UL-HGX44e



SV	Suction line	
DV	Discharge line	see technical data, Chapter 8
A	Connection suction side, not lockable	1/8" NPTF
A1	Connection suction side, lockable	7/16" UNF
B	Connection discharge side, not lockable	1/8" NPTF
B1	Connection discharge side, lockable	7/16" UNF
C	Connection oil pressure switch	1/8" NPTF
D	Connection oil pressure switch LP	7/16" UNF
D1	Connection oil return from oil separator	1/4" NPTF
F	Oil drain	M12 x 1.5
H	Oil charge plug	1/4" NPTF
I	Connection hot gas temperature sensor	1/8" NPTF
J	Connection oil sump heater	3/8" NPTF
K	Sight glass	3 x M6
L	Connection thermal protection thermostat	1/8" NPTF
M	Oil strainer	M12 x 1.5
O	Connection oil level regulator	3 x M6
P	Connection oil pressure differential sensor	M20x1.5
Q	Connection oil temperature sensor	1/8" NPTF
W	Connection for refrigerant injection	1/8" NPTF

10 | Dimensions and connections

UL-HGX56e



SV 90° rotatable
Dimensions in mm [inch]
Fig. 24

US

SV	Suction line	
DV	Discharge line	see technical data, Chapter 8
A	Connection suction side, not lockable	1/8" NPTF
A1	Connection suction side, lockable	7/16" UNF
B	Connection discharge side, not lockable	1/8" NPTF
B1	Connection discharge side, lockable	7/16" UNF
C	Connection oil pressure switch	1/8" NPTF
D	Connection oil pressure switch LP	7/16" UNF
D1	Connection oil return from oil separator	1/4" NPTF
F	Oil drain	M12 x 1.5
H	Oil charge plug	1/4" NPTF
I	Connection hot gas temperature sensor	1/8" NPTF
J	Connection oil sump heater	3/8" NPTF
K	Sight glass	3 x M6
L	Connection thermal protection thermostat	1/8" NPTF
M	Oil strainer	M12 x 1.5
O	Connection oil level regulator	3 x M6
P	Connection oil pressure differential sensor	M20x1.5
Q	Connection oil temperature sensor	1/8" NPTF
W	Connection for refrigerant injection	2x 1/8" NPTF

11 | Declaration of incorporation

Declaration of incorporation for incomplete machinery
in accordance with EC Machinery Directive 2006/42/EC, Annex II 1. B

Manufacturer: Bock GmbH
Benzstraße 7
72636 Frickenhausen, Germany

We, as manufacturer, declare in sole responsibility that the incomplete machinery

Name: Semi-hermetic compressor
Types: HG(X)12P/60-4 S (HC) HG(X)88e/3235-4(S) (HC)
UL-HGX12P/60 S 0,7 UL-HGX88e/3235 S 95
HG(X)12P/60 S 0,7 LG HG(X)88e/3235 (ML/S) 95 LG
HG(X)22(P)(e)/125-4 A HG(X)34(P)(e)/380-4 (S) A
HG(X)34(P)(e)/255-2 (A) HG(X)34(P)(e)/380-2 (A)(K)
HA(X)12P/60-4 HA(X)6/1410-4
HAX22e/125 LT 2 LG HAX44e/665 LT 14 LG
HG(X)12e/20-4 S CO₂ HG(X)44e/565-4 S CO₂
UL-HGX12e/20 S 0,7 CO₂ UL-HGX44e/565 S 31 CO₂
HG(X)12(e)/20-4 (ML/S/SH) CO₂ (L)T HG(X)56(e)/680-4 (ML/S/SH) CO₂ (L)T
UL-HGX12(e)/20 (ML/S/SH) 2 CO₂ (L)T UL-HGX56(e)/680 (ML/S/SH) 116 CO₂ (L)T
HGZ(X)7/1620-4 HGZ(X)7/2110-4
HGZ(X)66e/1340 LT 22 HGZ(X)66e/2070 LT 35
HRX40-2 CO₂ T H HRX60-2 CO₂ T H

Name: Open type compressor
Types: F(X)2 F(X)88/3235 (NH3)
FK(X)20/120 (K/N/TK) FK(X)50/980 (K/N/TK)

Serial number until 11/2025: BC00000A001 – BN99999Z999
Serial number starting 12/2025: 2549(DE/CZ/CN/IN/MX)000001 – 9953(DE/CZ/CN/IN/MX)999999

complies with the following provisions of the above-mentioned Directive:

According to Annex I, points 1.1.2, 1.1.3, 1.1.5, 1.3.2, 1.3.3, 1.3.7, 1.5.1, 1.5.2, 1.5.13 and 1.7.1 to 1.7.4 (excepted 1.7.4 f) are fulfilled.

Applied harmonised standards, in particular:

EN ISO 12100 :2010 Safety of machinery; General principles for design, risk assessment and risk reduction
EN 12693 :2008 Refrigerating systems and heat pumps; Safety and environmental requirements — Positive displacement refrigerant compressors

Remarks: We also declare that the special technical documentation for this incomplete machine has been created in accordance with Annex VII, Part B and we obligate to provide these upon reasoned request from the individual national authorities by data transfer.

Commissioning is prohibited until it has been confirmed that the machinery into which the incomplete machine above is to be incorporated complies with the EC Machinery Directive and an EC Declaration of Conformity, Annex II. 1. A exists.

Authorized person for compiling and handing over technical documentation:

Bock GmbH
Alexander Layh
Benzstraße 7
72636 Frickenhausen, Germany

Frickenhausen, 1st of December 2025



i. A. Alexander Layh, Global Head of R&D

11| Declaration of incorporation

Manufacturer: Bock GmbH
Benzstraße 7
72636 Frickenhausen, Germany



We, as manufacturer, declare in sole responsibility that the partly completed machinery

Name: Semi-hermetic compressor
Types: HG(X)12P/60-4 S (HC) HG(X)88e/3235-4(S) (HC)
UL-HGX12P/60 S 0,7 UL-HGX88e/3235 S 95
HGX12P/60 S 0,7 LG HGX88e/3235 (ML/S) 95 LG
HG(X)22(P)(e)/125-4 A HG(X)34(P)(e)/380-4 (S) A
HGX34(P)(e)/255-2 (A) HGX34(P)(e)/380-2 (A)(K)
HA(X)22e/125-4 HA(X)6/1410-4
HAX22e/125 LT 2 LG HAX44e/665 LT 14 LG
HGX12e/20-4 S CO₂ HGX44e/565-4 S CO₂
UL-HGX12e/20 S 0,7 CO₂ UL-HGX44e/565 S 31 CO₂
HGX12(e)/20-4 (ML/S/SH) CO₂ (L)T HGX56(e)/680-4 (ML/S/SH) CO₂ (L)T
UL-HGX12(e)/20 (ML/S/SH) 2 CO₂ (L)T UL-HGX56(e)/680 (ML/S/SH) 116 CO₂ (L)T
HGZ(X)7/1620-4 HGZ(X)7/2110-4
HGZ(X)66e/1340 LT 22 HGZ(X)66e/2070 LT 35
HRX40-2 CO₂ T H HRX60-2 CO₂ T H

Name: Open type compressor
Types: F(X)2 F(X)88/3235 (NH3)
FK(X)20/120 (K/N/TK)..... FK(X)50/980 (K/N/TK)

Serial number until 11/2025: BC00000A001 – BN99999Z999
Serial number starting 12/2025: 2549(DE/CZ/CN/IN/MX)000001 – 9953(DE/CZ/CN/IN/MX)999999

complies with the following provisions of the above-mentioned Statutory instrument:

According to Schedule 2, part1, points 1.1.2, 1.1.3, 1.1.5, 1.3.2, 1.3.3, 1.3.7, 1.5.1, 1.5.2, 1.5.13 and 1.7.1 to 1.7.4 (excepted 1.7.4 f) are fulfilled.

Designated standards: EN ISO 12100 :2010 Safety of machinery — General principles for design — Risk assessment and risk reduction
EN 12693 :2008 Refrigerating systems and heat pumps — Safety and environmental requirements — Positive displacement refrigerant compressors

Remarks: We also declare that the special technical documentation for this partly completed machine has been created in accordance with Annex II, 1. B and we obligate to provide these upon reasoned request from the individual national authorities by data transfer.

Commissioning is prohibited until it has been confirmed that the machinery into which the partly completed machine above is to be incorporated complies with the UK Statutory Instrument Supply machinery (Safety) regulations 2008 and an EC Declaration of Conformity, Annex II, 1. A exists.

Authorized representative for compiling and handing over technical documentation:

Danfoss LTD., 22 Wycombe End,
HP9 1NB, GB

Frickenhausen, 1st of December 2025

i. A. Alexander Layh, Global Head of R&D

US

12 | UL-Certificate of Compliance

Dear customer,

the Certificate of Compliance can be downloaded by the following QR-Code:



<https://vap.bock.de/stationaryapplication/Data/DocumentationFiles/UL-Certificateofconformity.pdf>

US

13 | Service

Dear customer,

if you have any questions about installation, operation and accessories, please contact our technical service or specialist wholesaler and/or our representative. The Bock service team can be contacted by phone, **+49 (0)7022 9454-0** or via **bock.info@danfoss.com**.

Yours faithfully Bock GmbH

US

Explore our solutions
danfoss.com



Danfoss can accept no responsibility for possible errors in catalogues, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without subsequential changes being necessary in specifications already agreed.

All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S.

All rights reserved.

BOCK®

Bock GmbH
Benzstraße 7
72636 Frickenhausen
Germany
Phone +49 7022 9454-0
Fax +49 7022 9454-137
bock.danfoss.com

© Bock GmbH