

Spare part list for EX-HGX7/1860-4 3G

Position	Item No.	Description	Quantity
20	06696	BASE PLATE H=24.0	1 pc
30	51230	GASKET-BASE PLATE	1 pc
40	05539	HEX.HEAD SCREW M10X30	20 pc
50	06761	GASKET-LOWER VALVE PLATE ø75	3 pc
60	07845	VALVE PLATE CPL. ø70/75/80 ONLY AVAIL.AS COM.AS.KIT/ITEM: 2000	3 pc
70	06486	GASKET-UPPER VALVE PLATE	3 pc
100	07940	DECOMPRESSION VALVE M24X1,5 ONLY AVAIL.AS COM.AS.KIT/ITEM: 2000	3 pc
110	05791	SEAL RING 24,2x27,8x2	3 pc
120	07855	PRESSURE BALANCE VALVE CPL.	2 pc
170	03643	CYLINDER COVER STANDARD	1 pc
175	03643	CYLINDER COVER STANDARD	2 pc
178	05514	LOCKING SCREW 1/8"NPTF	3 pc
180	06828	HEX.HEAD SCREW M10X75	39 pc
210	05097	GASKET RING 70X54X1,0	1 pc
220	06684	HEX.HEAD SCREW M12X85	4 pc
270	05993	PISTON PIN ø20X13X66 ONLY AVAIL.AS COM.AS.KIT/ITEM: 2030	6 pc
280	05569	CIRCLIP 20X1 DIN 472	12 pc
290	06712	DOUBLE BEVEL OIL CONT.RING 75	6 pc
295	50845	OIL SCRAPER RING PISTON 75	6 pc
300	06710	TAPERED COMPR.RING PIS.75 CHR.	6 pc
331	52243	CAP NUT M27X2 ADDITIONAL SEAL RING 25x18x1,5 POS.333 NECESSARY	1 ST
332	05800 05545 05528	SCREW-IN FITTING DIN 8906 SEALING CAP 7/16"UNF UNION NUT 7/16"UNF	1 pc 1 pc 1 pc
333	52185	SEAL RING 25x18x1,5 FOR CAP NUT M27X2 NOT SHOWN	1 ST
340	05113	GASKET RING 52X38X1,0	1 pc
350	06009	SOLDERED BUSH ø42	1 pc
360	05787	SQUARE FLANGE (NS32-38)	1 pc
371	51917	CAP NUT M36X1,5 ADDITIONAL SEAL RING 34X28X2 POS.373 NECESSARY	1 ST
	52186	CAP NUT M27X2 ADDITIONAL SEAL RING 25X18X1,5 POS.373 NECESSARY	1 ST
372	05800 05545	SCREW-IN FITTING DIN 8906 SEALING CAP 7/16"UNF	1 pc 1 pc

	05528	UNION NUT 7/16"UNF	1 pc
373	06123	SEAL RING 34x28x2 FOR CAP NUT M36X1,5 NOT SHOWN	1 ST
	52185	SEAL RING 25x18x1,5 FOR CAP NUT M27X2 NOT SHOWN	1 ST
374	05112	GASKET RING 75X61X1,0	1 pc
375	05798	SOLDERED BUSH ø54	1 pc
376	05785	SQUARE FLANGE (NS50)	1 pc
377	05415	HEX.HEAD SCREW M16X50	4 pc
380	05463	HEX.HEAD SCREW M12X50	4 pc
460	07788	OIL PUMP COMPLETE	1 pc
470	05094	GASKET-F.OIL P.+REAR BEAR.FL.	1 pc
480	05421	HEX.HEAD SCREW M8X25	6 pc
485	05426	HEX.HEAD SCREW M8X40	2 pc
490	06723	OIL STRAINER	1 pc
500	05342	SEAL RING 22x27x2	3 pc
505	50055	LOCKING SCREW W.MAGNET	1 pc
506	06400	LOCKING SCREW M22X1,5	1 pc
508	05801	LOCKING SCREW 1/4"NPTF	1 pc
510	06348	LOCKING SCREW M22X1,5	1 pc
520	05514	LOCKING SCREW 1/8"NPTF	5 pc
527	05801	LOCKING SCREW 1/4"NPTF	2 pc
530	05752	T-PIECE WITH SCHRADER CONNECT.	1 pc
532	05514	LOCKING SCREW 1/8"NPTF	1 pc
540	51723	SCREW-IN ANGLE PIECE DIN 8906	1 pc
570	06082	SIGHT GLASS ø60 ONLY AVAIL.AS COM.AS.KIT/ITEM: 2080	2 pc
580	05402	HEX.HEAD SCREW M6X16	6 pc
590	06218	O-RING ø32,99x2,62 FOR MINERAL OIL-VERSION	2 pc
	51904	O-RING ø32,99x2,62; X-VERSION FOR ESTER OIL/X-VERSION	2 pc
600	06237	RING SCREW M16	1 pc
625	07803	NON-RETURN VALVE ø12 CPL.	1 pc
740	51603	REAR BEARING FLANGE	1 pc
744	50232	THREADED PIN M8X1,25/8 LONG	2 pc
750	05539	HEX.HEAD SCREW M10X30	10 pc
765	06878	GASKET-REAR BEARING FLANGE	1 pc
770	05691	CYLINDER PIN 6M6x15	1 pc
790	06879	FEATHER KEY A9,56X8X60 DIN6885	1 pc

800	04425	DISC ø50X12,5X8	1 pc
810	05666	SPRING WASHER B12	1 pc
820	06836	HEX.HEAD SCREW M12X40/PREC.	1 pc
1000	04274	MOTOR COVER/PAINTED	1 pc
1010	05455	HEX.HEAD SCREW M10X110	8 pc
1015	06882	HEX.HEAD SCREW M10X170	2 pc
1017	06883	O-RING ø278,77X5,33 FOR MINERAL OIL-VERSION	1 pc
	51908	O-RING ø278,77x5,33; X-VERSION FOR ESTER OIL/X-VERSION	1 pc
1020	50060	THREADED PIN M8X20/PREC.	2 pc
1022	06880	FEATHER KEY A4,63X5X70	1 pc
1030	06877	MOTOR FOOT	1 pc
1040	05091	COUNTERSUNK SCREW M10X35	2 pc
1050	06864	TERMINAL BOARD	1 pc
1060	06876	GASKET-TERMINAL BOARD	1 pc
1070	05447	HEX.HEAD SCREW M10X35 FOR SERIAL VOLTAGE	10 pc
1080	33529	TERMINAL BOX CPL./ST,BLUE *EX SERIAL	1 pc
	51348	TERMINAL BOX CPL./ST,BLUE *EX FOR OFFSHORE	1 pc
1090	06872	GASKET-TERMINAL BOX	1 pc
1100	06061	HEX.HEAD SCREW M6X12 - A2	4 pc
1103	05418	HEX.HEAD SCREW M8X16 - A2	1 pc
1110	05664	SERRATED WASHER A6,4	4 pc
1120	06043	LOCK WASHER S M6	12 pc
1123	05654	LOCK WASHER S M8 - A2	1 pc
1125	05654	LOCK WASHER S M8 - A2	8 pc
1130	05916	BRIDGE FOR TERMINAL BOARD	3 pc
1131	51346	DISC ø24X8,4X2	6 pc
1150	05629	HEX.HEAD NUT M8 - A2	6 pc
1160	06626	HEX.HEAD SCREW M6X10	6 pc
1170	06097	STATOR 33KW D/SSS NOT AVAILABLE ANYMORE/INACTIVE FOR HG(X)7/1860-4 UP TO DESIGN KEY 039	1 pc
	70199	STATOR 33KW S/SS [PW50:50] FOR HG(X)7/1860-4 AS OF DESIGN KEY 040	1 pc
	06098	STATOR 37KW D/SSS FOR HG(X)7/1860-4 S UP TO DESIGN KEY 039	1 pc
	70200	STATOR 37KW S/SS [PW50:50] FOR HG(X)7/1860-4 S AS OF DESIGN KEY 040	1 pc
1175	06093	ROTOR 33KW FOR HG(X)7/1860-4 UP TO DESIGN KEY 039	1 pc
	70203	ROTOR 33KW/37KW/40KW FOR HG(X)7/1860-4	1 pc

	06094	AS OF DESIGN KEY 040 ROTOR 37KW FOR HG(X)7/1860-4 S	1 pc
	70203	UP TO DESIGN KEY 039 ROTOR 33KW/37KW/40KW FOR HG(X)7/1860-4 S AS OF DESIGN KEY 040	1 pc
1190	05983	FILTER SUCTION SIDE	1 pc
1210	05111	GASKET RING 81,5X60X1	2 pc
1220	05755	HEX.HEAD SCREW M16X110	4 pc
1520	08876	SET-ANTI-VIBRATION PADS	1 pc
1999		----- ASSEMBLY KITS -----	1 pc
2000	08498	SET-VALVE PLATE FOR HG(X)7	3 pc
2020	80116	SET-OIL PUMP	1 pc
2030	80048	SET-PISTON ø75	6 pc
2040	08996	SET-PISTON-CONN.W.3 RINGS/75 NOT AVAILABLE ANYMORE/INACTIVE	6 pc
2050	80092	SET-CRANKSHAFT 70 STROKE	1 pc
2060	08398	SET-SHUT-OFF VALVE NS38	1 pc
2070	08087	SET-SHUT-OFF VALVE NS50	1 pc
2080	80093	SET-SIGHT GLASS ø60	2 pc
2090	80094	SET-GASKETS NOT SHOWN	1 pc
2100	08306	SET-CONNECTING ROD	6 pc
2110	80198	SET-REAR BEARING FLANGE	1 pc
2130	80182	SET-MOTOR 33KW D/SSS NOT AVAILABLE ANYMORE/INACTIVE FOR HG(X)7/1860-4 UP TO DESIGN KEY 039	1 pc
	81238	SET-MOTOR 33KW S/SS [PW50:50] FOR HG(X)7/1860-4	1 pc
	80183	AS OF DESIGN KEY 040 SET-MOTOR 37KW D/SSS FOR HG(X)7/1860-4 S UP TO DESIGN KEY 039	1 pc
	81258	SET-MOTOR 37KW S/SS [PW50:50] FOR HG(X)7/1860-4 S AS OF DESIGN KEY 040	1 pc
2160	81197	SET-TERMINAL BOARD *EX	1 pc
2170	81202	SET-INSULATION PLATE *EX	1 pc
2190	80426 80578	SET-MOTOR PROT.MP10,AC 230V*EX SET-MOTOR PROT.MP10,DC 24V *EX SPECIAL VERSION	1 pc 1 pc
2220	80076	SET-OIL STRAINER	1 pc
2230	80178	SET-BEARING BUSH ASS.HG7+76e COMPATIBLE AS OF BUILT 06/2010	1 pc
2999		----- ACCESSORIES -----	1 pc
3200	81184	SET-CAP.REG.CR92 230V AC *EX	1 pc
3300	81183	SET-CR92 230V AC *EX	1 pc
3310	80519	SET-VALVE BODY CR92 *EX	1 pc

3311	05986	O-RING ø45,69X2,62 GREEN FOR MINERAL OIL-VERSION	1 pc
	51901	O-RING ø45,69x2,62; X-VERSION FOR ESTER OIL/X-VERSION	1 pc
3320	81147	SET-SOLENOID COIL 230V AC *EX	1 pc
3600	07946	SHUT-OFF VALVE 1/4"NPTF-7/16"	1 pc
3700	81196	SET-OIL PRESS.SENSOR/INT *EX	1 pc
	82021	SET-OIL PRESS.SENSOR/INT *EX FOR OFFSHORE	1 pc
3710	60018	INT250 SWITCH PART *EX	1 pc
3712	60060	MULTIFUNCTION TIME RELAIS *EX	1 pc
3714	60060	MULTIFUNCTION TIME RELAIS *EX	1 pc
3720	82202	SET-SCREW-IN P.DELTA-P/INT250	1 pc
3730	52031	O-RING ø10,5x1,5 FOR MINERAL OIL-VERSION	1 pc
	51924	O-RING ø10,5x1,5; X-VERSION FOR ESTER OIL/X-VERSION	1 pc
3740	05724	SEAL RING 26x20x1,5 NOT SHOWN	1 pc
3800	81245	SET-THERM PROT.TH.1/8"NPTF *EX	1 pc
	82022	SET-THERM PROT.TH.1/8"NPTF *EX FOR OFFSHORE	1 pc
3950	81193	SET-OILS.HEAT.240W 230V AC *EX	1 pc
	82020	SET-OILS.HEAT.240W 230V AC *EX FOR OFFSHORE	1 pc
3952	05342	SEAL RING 22x27x2	1 pc
3954	52218	SEAL RING 24x16x2	1 pc
3956	51552	CABLE SCREW EX d M16X1,5	1 pc
3958	51809	CABLE SCREW EX e M16X1,5	1 pc
	51822	HEX.HEAD NUT M16X1,5	1 pc
	51359	CABLE SCREW EX e M16X1,5 FOR OFFSHORE	1 pc
	51991	HEX.HEAD NUT M16X1,5 FOR OFFSHORE	1 pc
3999	02524	OIL BOCKLub A46 / 1 LTR.CAN	1 pc
	02525	OIL BOCKLub A46 / 5 LTR.CAN NOT SHOWN	1 pc
	02520	ONLY FOR R22-COMPRESSORS ! OIL BOCKLub E55 / 1 LTR.CAN	1 pc
	02521	OIL BOCKLub E55 / 5 LTR.CAN	1 pc
	02522	OIL BOCKLub E55 / 10 LTR.CAN NOT SHOWN	1 pc
		ONLY FOR X-COMPRESSORS !	