

Spare part list for SFDX88/3235

Position	Item No.	Description	Quantity
10	11516 11517 11518 11519	F88/2735 F88/3235 FX88/2735 FX88/3235	1 pc 1 pc 1 pc 1 pc
11		-----	1 pc
20	33439	BASE FRAME	1 pc
21		-----	1 pc
30	51474 60053 60054	CLUTCH BoWex 80-225, 60F7/60H7 ONLY FOR 37,0+45,0 KW MOTOR CLUTCH BoWex 80-225, 65F7/60H7 ONLY FOR 55,0 KW MOTOR CLUTCH BoWex 80-225, 75F7/60H7 ONLY FOR 75,0/90,0 KW MOTOR	1 pc 1 pc 1 pc
31		-----	1 pc
50	60061 60062 60043 60046 60047	DK-MOTOR 37,0 KW,IP55,225S DK-MOTOR 45,0 KW,IP55,225M DK-MOTOR 55,0 KW,IP55,250M DK-MOTOR 75,0 KW,IP55,280S DK-MOTOR 90,0 KW,IP55,280M	1 pc 1 pc 1 pc 1 pc 1 pc
51		-----	1 pc
60	33555	DISTANCE PIECE ø83X24,7	4 pc
70	06073	HEX.HEAD SCREW M16X80	4 pc
75	06070	DISC ø34X17X3	4 pc
80	05633	HEX.HEAD NUT M16	4 pc
90	05771	SPRING WASHER B16	4 pc
170	06968	RING SCREW M20	4 pc
2000		----- ASSEMBLY KITS -----	1 pc
2750	80988	SET-CLUTCH HOUSING	1 pc
2999		----- ACCESSORIES -----	1 pc
3400	81350	SET-HP PRESSURE LIMITER + HP SAFETY-PRES.LIMITER	1 pc
3500	08668	SET-INSTRUM.PANEL (W.3 GAUGES)	1 pc
3510	04977	INSTRUMENT PANEL (W/O 3 GAUG.)	1 pc
3511	03571	BRACKET F.INSTRUMENT PANEL	1 pc
3512	05233	HEX.HEAD SCREW M8X20	2 pc
3513	05663	SPRING WASHER A8	6 pc
3514	05629	HEX.HEAD NUT M8 - A2	6 pc
3515	05418	HEX.HEAD SCREW M8X16 - A2	6 pc
3516	07550	HP LIMITER+HP SAFETY CUT-OUT	1 pc
3517	50107	HEX.HEAD SCREW M4X12	2 pc
3520	07667	HIGH PRES.GAUGE,-1 UP TO 24BAR	1 pc
3530	07668	LOW PRES.GAUGE,-1 UP TO 9 BAR	1 pc
3540	07557	OIL PRES.GAUGE,-1 UP TO 16 BAR	1 pc

3550	07584	PRESSURE-GAUGE VALVE	3 pc
3560	06061	HEX.HEAD SCREW M6X12 - A2	6 pc
3570	05662	SPRING WASHER B6	6 pc
3580	05628	HEX.HEAD NUT M6	6 pc
3590	05528	UNION NUT 7/16"UNF	5 pc
3999	02524	OIL BOCKLub A46 / 1 LTR.CAN	1 pc
	02525	OIL BOCKLub A46 / 5 LTR.CAN	1 pc
		NOT SHOWN	
		ONLY FOR R22-COMPRESSORS !	
	02520	OIL BOCKLub E55 / 1 LTR.CAN	1 pc
	02521	OIL BOCKLub E55 / 5 LTR.CAN	1 pc
	02522	OIL BOCKLub E55 / 10 LTR.CAN	1 pc
		NOT SHOWN	
		ONLY FOR X-COMPRESSORS !	