

Spare part list for SHAX34P/215-4 RU

Position	Item No.	Description	Quantity
10	14363	MC- HA34P/215-4	1 pc
	14364	MC- HA34P/255-4	1 pc
	14365	MC- HA34P/315-4 SERVICE	1 pc
	14366	MC- HA34P/380-4	1 pc
	14367	MC- HAX34P/215-4	1 pc
	14368	MC- HAX34P/255-4	1 pc
	14369	MC- HAX34P/315-4	1 pc
	14370	MC- HAX34P/380-4 -----	1 pc
20	60031	REFRIGERANT RECEIVER 7 LTR.	1 pc
1520	08579	SET-RUBBER PLATE INDIVIDUALLY ADDED	1 pc
2000		----- ASSEMBLY KITS -----	1 pc
2200	80320	SET-ANTI-VIBRATION PADS	1 pc
2999		----- ACCESSORIES -----	1 pc
3100	07302	OIL SEPARATOR OS-16	1 pc
3110	60015	HOLDING ANGLE F.OIL SEPARATOR	1 pc
3300	81114	SET-SAFETY VALVE (28BAR) FOR GVN REFRIGERANT RECEIVER POSITION NOT SHOWN	1 pc
	08612	SET-SAFETY VALVE (28BAR) FOR BWB REFRIGERANT RECEIVER POSITION NOT SHOWN	1 pc
3400	81122	SET-HIGH-PRESS./SAFETY/GUARD	1 pc
3999	02279	REFR.MACH.OIL SP46 / 1 LTR.CAN	1 pc
	02280	REFR.MACH.OIL SP46 / 5 LTR.CAN	1 pc
	02281	REFR.MACH.OIL SP46 /20 LTR.CAN NOT SHOWN	1 pc
		ONLY FOR R22-COMPRESSORS !	
	02282	REFR.MACH.OIL SE55 / 1 LTR.CAN	1 pc
	02283	REFR.MACH.OIL SE55 / 5 LTR.CAN	1 pc
	02284	REFR.MACH.OIL SE55 /10 LTR.CAN NOT SHOWN	1 pc
		ONLY FOR X-COMPRESSORS !	