

Spare part list for SHGX34e/215-4 SPB (as of DK 057)

Position	Item No.	Description	Quantity
10	28094 28098 28102 28106 28095 28099 28103 28107 28096 28100 28104 28108 28097 28101 28105 28109	HG34e/215-4 HG34e/215-4 S HGX34e/215-4 HGX34e/215-4 S HG34e/255-4 HG34e/255-4 S HGX34e/255-4 HGX34e/255-4 S HG34e/315-4 HG34e/315-4 S HGX34e/315-4 HGX34e/315-4 S HG34e/380-4 HG34e/380-4 S HGX34e/380-4 HGX34e/380-4 S -----	1 pc 1 pc 1 pc 1 pc 1 pc 1 pc 1 pc 1 pc 1 pc 1 pc 1 pc 1 pc 1 pc 1 pc 1 pc 1 pc 1 pc
20	60028 60029	REFRIGERANT RECEIVER 8 LTR. FOR SHG(X)34e/215+255+315 PB FOR SHG(X)34e/215+255 SPB REFRIGERANT RECEIVER 10 LTR. FOR SHG(X)34e/380 PB FOR SHG(X)34e/315+380 SPB	1 ST 1 ST
22	51301	SEAL RING 19,5x16,5x1,5 (f.1")	1 pc
23	51307	LOCKING SCREW 1/2" NPTF	1 pc
30	51066 51067	CASING W. AIR-COOLED COND. 2RR FOR SHG(X)34e/215+255+315 PB FOR SHG(X)34e/215+255 SPB NOT AVAILABLE SEPARATELY CASING W. AIR-COOLED COND. 3RR FOR SHG(X)34e/380 PB FOR SHG(X)34e/315+380 SPB NOT AVAILABLE SEPARATELY	1 ST 1 ST
1520	08579	SET-RUBBER PLATE	1 pc
1999		----- ASSEMBLY KITS -----	1 pc
2000	80327	SET-HOLDING ANGLE	1 pc
2020	82423 82424	SET-AIR-COOLED CONDENSOR FOR SHG(X)34e/215+255+315 PB FOR SHG(X)34e/215+255 SPB SET-AIR-COOLED CONDENSOR FOR SHG(X)34e/380 PB FOR SHG(X)34e/315+380 SPB	1 ST 1 ST
2024	82296	SET-SHUT-OFF VALVE 5/8"/SOLD.	1 pc
2025	81399	SET-SIGHT GLASS	1 pc
2030	82302	SET-O-RINGS	1 pc
2100	81207	SET-VENTILAT.CPL.ø630 230V AC	1 pc
2200	81490	SET-ANTI-VIBRATION PADS	1 pc
2999		----- ACCESSORIES -----	1 pc
3100	81116 81119	SET-OIL SEPARATOR OS-16 FOR SHG(X)34e/215+255+315 PB FOR SHG(X)34e/215+255 SPB SET-OIL SEPARATOR OS-22 FOR SHG(X)34e/380 PB FOR SHG(X)34e/315+380 SPB	1 ST 1 ST
3200	81205 81206	SET-DISCHARGE A.SUCTION PIPING ø 12 FOR SHG(X)34e/215+255+315 PB FOR SHG(X)34e/215+255 SPB SET-DISCHARGE A.SUCTION PIPING	1 ST 1 ST

		ø 16 FOR SHG(X)34e/380 PB FOR SHG(X)34e/315+380 SPB	
3300	81114	SET-SAFETY VALVE (28BAR)	1 pc
	08612	FOR GVN REFRIGERANT RECEIVER SET-SAFETY VALVE (28BAR) NOT AVAILABLE ANYMORE/INACTIVE FOR BWB REFRIGERANT RECEIVER	1 pc
3400	81122	SET-HIGH-PRESS./SAFETY/GUARD +LOW PRESSURE CONTROLLER	1 pc
3500	81140	SET-OIL PRESS. SAFETY SW. MP55	1 pc
3510	81208	SET-FREQUENCY CONVER.7,5KW FOR SHG(X)34e/215+255 PB	1 ST
	81210	FOR SHG(X)34e/215+255 SPB SET-FREQUENCY CONVER.7,5KW FOR SHG(X)34e/315 PB	1 ST
	81211	SET-FREQUENCY CONVER.11KW FOR SHG(X)34e/380 PB FOR SHG(X)34e/315+380 SPB	1 ST
3520	81426	SET-CABINET 1 PLUSBOX FOR SHG(X)34e/215+255 PB FOR SHG(X)34e/215 SPB	1 ST
	81427	SET-CABINET 2 PLUSBOX FOR SHG(X)34e/255 SPB FOR SHG(X)34e/315 PB	1 ST
	81428	SET-CABINET 3 PLUSBOX FOR SHG(X)34e/315 SPB FOR SHG(X)34e/380 PB	1 ST
	81429	SET-CABINET 4 PLUSBOX FOR SHG(X)34e/380 SPB	1 ST
	81430	SET-CABINET 1 PLUSBOX F.EFC FOR SHG(X)34e/215 PB	1 ST
	81431	SET-CABINET 2 PLUSBOX F.EFC FOR SHG(X)34e/215+255 SPB FOR SHG(X)34e/255+315 PB	1 ST
	81432	SET-CABINET 3 PLUSBOX F.EFC FOR SHG(X)34e/315 SPB FOR SHG(X)34e/380 PB	1 ST
	81433	SET-CABINET 4 PLUSBOX F.EFC FOR SHG(X)34e/380 SPB	1 ST
3560	81204	SET-VENTILAT.CPL.ø630 230V EC	1 pc
3600	80937	SET-SPEED CONTROLLER XGE-4C	1 pc
3999	02524	OIL BOCKLub A46 / 1 LTR.CAN	1 pc
	02525	OIL BOCKLub A46 / 5 LTR.CAN NOT SHOWN ONLY FOR R22-COMPRESSORS !	1 pc
	02520	OIL BOCKLub E55 / 1 LTR.CAN	1 pc
	02521	OIL BOCKLub E55 / 5 LTR.CAN	1 pc
	02522	OIL BOCKLub E55 / 10 LTR.CAN NOT SHOWN ONLY FOR X-COMPRESSORS !	1 pc