

Spare part list for SHGX34e/315-4 PB (up to DK 056)

Position	Item No.	Description	Quantity
10	14355	MC- HG34e/215-4	1 pc
	14359	MC- HGX34e/215-4	1 pc
	14371	MC- HG34e/215-4 S	1 pc
	14375	MC- HGX34e/215-4 S	1 pc
	14356	MC- HG34e/255-4	1 pc
	14360	MC- HGX34e/255-4 SERVICE	1 pc
	14372	MC- HG34e/255-4 S	1 pc
	14376	MC- HGX34e/255-4 S	1 pc
	14357	MC- HG34e/315-4	1 pc
	14361	MC- HGX34e/315-4	1 pc
	14373	MC- HG34e/315-4 S	1 pc
	14377	MC- HGX34e/315-4 S	1 pc
	14358	MC- HG34e/380-4	1 pc
	14362	MC- HGX34e/380-4	1 pc
	14374	MC- HG34e/380-4 S	1 pc
	14378	MC- HGX34e/380-4 S -----	1 pc
20	60028	REFRIGERANT RECEIVER 8 LTR. FOR SHG(X)34e/215+255+315 PB FOR SHG(X)34e/215+255 SPB	1 ST
	60029	REFRIGERANT RECEIVER 10 LTR. FOR SHG(X)34e/380 PB FOR SHG(X)34e/315+380 SPB	1 ST
30	51066	CASING W. AIR-COOLED COND. 2RR FOR SHG(X)34e/215+255+315 PB FOR SHG(X)34e/215+255 SPB	1 ST
	51067	CASING W. AIR-COOLED COND. 3RR FOR SHG(X)34e/380 PB FOR SHG(X)34e/315+380 SPB	1 ST
1520	08579	SET-RUBBER PLATE INDIVIDUALLY ADDED	1 pc
1999		----- ASSEMBLY KITS -----	1 pc
2000	80327	SET-HOLDING ANGLE	1 pc
2100	81207	SET-VENTILAT.CPL.ø630 230V AC	1 pc
2200	80320	SET-ANTI-VIBRATION PADS	1 pc
2999		----- ACCESSORIES -----	1 pc
3100	81116	SET-OIL SEPARATOR OS-16 FOR SHG(X)34e/215+255+315 PB FOR SHG(X)34e/215+255 SPB	1 ST
	81119	SET-OIL SEPARATOR OS-22 FOR SHG(X)34e/380 PB FOR SHG(X)34e/315+380 SPB	1 ST
3200	81205	SET-DISCHARGE A.SUCTION PIPING ø 12 FOR SHG(X)34e/215+255+315 PB FOR SHG(X)34e/215+255 SPB	1 ST
	81206	SET-DISCHARGE A.SUCTION PIPING ø 16 FOR SHG(X)34e/380 PB FOR SHG(X)34e/315+380 SPB	1 ST
3300	81114	SET-SAFETY VALVE (28BAR) FOR GVN REFRIGERANT RECEIVER	1 pc
	08612	SET-SAFETY VALVE (28BAR) FOR BWB REFRIGERANT RECEIVER	1 pc
3400	81122	SET-HIGH-PRESS./SAFETY/GUARD	1 pc
3500	80937	SET-SPEED CONTROLLER XGE-4C	1 pc
3510	81208	SET-FREQUENCY CONVER.7,5KW FOR SHG(X)34e/215+255 PB FOR SHG(X)34e/215+255 SPB	1 ST
	81210	SET-FREQUENCY CONVER.7,5KW FOR SHG(X)34e/315 PB	1 ST
	81211	SET-FREQUENCY CONVER.11KW	1 ST

		FOR SHG(X)34e/380 PB FOR SHG(X)34e/315+380 SPB	
3520	81426	SET-CABINET 1 PLUSBOX FOR SHG(X)34e/215+255 PB	1 ST
	81427	SET-CABINET 2 PLUSBOX FOR SHG(X)34e/255 SPB	1 ST
	81428	SET-CABINET 3 PLUSBOX FOR SHG(X)34e/315 PB	1 ST
	81429	SET-CABINET 4 PLUSBOX FOR SHG(X)34e/380 PB	1 ST
	81430	SET-CABINET 1 PLUSBOX F.EFC FOR SHG(X)34e/215 PB	1 ST
	81431	SET-CABINET 2 PLUSBOX F.EFC FOR SHG(X)34e/215+255 SPB	1 ST
	81432	SET-CABINET 3 PLUSBOX F.EFC FOR SHG(X)34e/315 PB	1 ST
	81433	SET-CABINET 4 PLUSBOX F.EFC FOR SHG(X)34e/380 PB	1 ST
3560	81204	SET-VENTILAT.CPL.ø630 230V EC	1 pc
3999	02279	REFR.MACH.OIL SP46 / 1 LTR.CAN	1 pc
	02280	REFR.MACH.OIL SP46 / 5 LTR.CAN	1 pc
	02281	REFR.MACH.OIL SP46 /20 LTR.CAN NOT SHOWN	1 pc
	02282	ONLY FOR R22-COMPRESSORS ! REFR.MACH.OIL SE55 / 1 LTR.CAN	1 pc
	02283	REFR.MACH.OIL SE55 / 5 LTR.CAN	1 pc
	02284	REFR.MACH.OIL SE55 /10 LTR.CAN NOT SHOWN ONLY FOR X-COMPRESSORS !	1 pc