

Spare part list for SHGX34e/315-4 SL (up to DK 075)

Position	Item No.	Description	Quantity
10	14373 14358 14377 14362	MC- HG34e/315-4 S MC- HG34e/380-4 MC- HGX34e/315-4 S MC- HGX34e/380-4 -----	1 pc 1 pc 1 pc 1 pc
20	60032	REFRIGERANT RECEIVER 14 LTR.	1 pc
30	07953	AIR-COOLED CONDENSOR	1 pc
50	03418	BASE ANGLE (PAIR)	1 pc
1520	08579	SET-RUBBER PLATE INDIVIDUALLY ADDED	1 pc
2000		----- ASSEMBLY KITS -----	1 pc
2100	08837	SET-VENTILATOR C.ø450 230V AC	2 pc
2200	80320	SET-ANTI-VIBRATION PADS	1 pc
2999		----- ACCESSORIES -----	1 pc
3100	81116	SET-OIL SEPARATOR OS-16	1 pc
3110	03454	BRACKET F.OIL SEPARATOR	1 pc
3300	81114 08612	SET-SAFETY VALVE (28BAR) FOR GVN REFRIGERANT RECEIVER SET-SAFETY VALVE (28BAR) FOR BWB REFRIGERANT RECEIVER	1 pc 1 pc
3400	81122	SET-HIGH-PRESS./SAFETY/GUARD	1 pc
3500	81140	SET-OIL PRESS. SAFETY SW. MP55	1 pc
3999	02279 02280 02281 02282 02283 02284	REFR.MACH.OIL SP46 / 1 LTR.CAN REFR.MACH.OIL SP46 / 5 LTR.CAN REFR.MACH.OIL SP46 /20 LTR.CAN NOT SHOWN ONLY FOR R22-COMPRESSORS ! REFR.MACH.OIL SE55 / 1 LTR.CAN REFR.MACH.OIL SE55 / 5 LTR.CAN REFR.MACH.OIL SE55 /10 LTR.CAN NOT SHOWN ONLY FOR X-COMPRESSORS !	1 pc 1 pc 1 pc 1 pc 1 pc 1 pc