

Spare part list for SHGX44e/565-4 L (as of DK 076)

Position	Item No.	Description	Quantity
10	28110 28112 28111 28113	HG44e/475-4 HGX44e/475-4 HG44e/565-4 HGX44e/565-4 -----	1 pc 1 pc 1 pc 1 pc
20	60032	REFRIGERANT RECEIVER 14 LTR.	1 pc
22	51301	SEAL RING 19,5x16,5x1,5 (f.1")	1 pc
23	51307	LOCKING SCREW 1/2" NPTF	1 pc
30	07954 70469	AIR-COOLED CONDENSOR UP TO DESIGN KEY 075 COND.NOT AVAILABLE ANYMORE REPLACED BY POS. 30+50+2100, DESIGN KEY 076 AIR-COOLED CONDEN.4RR/28RH/12K AS OF DESIGN KEY 076	1 pc 1 pc
50	03418 52162	BASE ANGLE (PAIR) UP TO DESIGN KEY 075 NOT AVAILABLE ANYMORE/INACTIVE BASE ANGLE (PAIR) AS OF DESIGN KEY 076	1 pc 1 pc
1520	08579	SET-RUBBER PLATE	1 pc
2000		----- ASSEMBLY KITS -----	1 pc
2024	82296	SET-SHUT-OFF VALVE 5/8"/SOLD.	1 pc
2025	81399	SET-SIGHT GLASS	1 pc
2030	82302	SET-O-RINGS	1 pc
2100	82125 82222	SET-VENTILAT.CPL.ø450 230V AC UP TO DESIGN KEY 075 SET-VENTILAT.CPL.ø450 230V AC AS OF DESIGN KEY 076	2 pc 2 pc
2200	80938	SET-ANTI-VIBRATION PADS	1 pc
2999		----- ACCESSORIES -----	1 pc
3100	81118	SET-OIL SEPARATOR OS-35F	1 pc
3110	03454	BRACKET F.OIL SEPARATOR	1 pc
3300	81114	SET-SAFETY VALVE (28BAR)	1 pc
3400	81122	SET-HIGH-PRESS./SAFETY/GUARD +LOW PRESSURE CONTROLLER	1 pc
3999	02524 02525 02520 02521 02522	OIL BOCKLub A46 / 1 LTR.CAN OIL BOCKLub A46 / 5 LTR.CAN NOT SHOWN ONLY FOR R22-COMPRESSORS ! OIL BOCKLub E55 / 1 LTR.CAN OIL BOCKLub E55 / 5 LTR.CAN OIL BOCKLub E55 / 10 LTR.CAN NOT SHOWN ONLY FOR X-COMPRESSORS !	1 pc 1 pc 1 pc 1 pc 1 pc