

Spare part list for SHGX44e/770-4 L (up to DK 075)

Position	Item No.	Description	Quantity
10	14903 14911 14907 14915	MC- HG44e/770-4 MC- HGX44e/770-4 MC- HG44e/770-4 S MC- HGX44e/770-4 S -----	1 pc 1 pc 1 pc 1 pc
20	60033 60034	REFRIGERANT RECEIVER 23 LTR. FOR SHG44e/770 L REFRIGERANT RECEIVER 35 LTR. FOR SHG44e/770 SL	1 ST 1 ST
30	07956 70134	AIR-COOLED CONDENSOR FOR SHG44e/770 L AIR-COOLED CONDENSOR FOR SHG44e/770 SL	1 ST 1 ST
50	03418	BASE ANGLE (PAIR)	1 pc
1520	08579	SET-RUBBER PLATE INDIVIDUALLY ADDED	1 pc
2000		----- ASSEMBLY KITS -----	1 pc
2100	08837 80332	SET-VENTILATOR C.ø450 230V AC FOR SHG44e/770 L SET-VENTILAT.CPL.ø500 230V AC FOR SHG44e/770 SL	2 ST 4 ST
2200	80938	SET-ANTI-VIBRATION PADS	1 pc
2999		----- ACCESSORIES -----	1 pc
3100	81121	SET-OIL SEPARATOR OS-42FL	1 pc
3110	03454	BRACKET F.OIL SEPARATOR	1 pc
3300	81114	SET-SAFETY VALVE (28BAR)	1 pc
3400	81122	SET-HIGH-PRESS./SAFETY/GUARD	1 pc
3500	08567	SET-INSTRUM.PANEL (W.3 GAUGES)	1 pc
3510	03413	INSTRUMENT PANEL (W/O 3 GAUG.)	1 pc
3520	07667	HIGH PRES.GAUGE,-1 UP TO 24BAR	1 pc
3530	07668	LOW PRES.GAUGE,-1 UP TO 9 BAR	1 pc
3540	07557	OIL PRES.GAUGE,-1 UP TO 16 BAR	1 pc
3550	07584	PRESSURE-GAUGE VALVE	3 pc
3560	05402	HEX.HEAD SCREW M6X16	6 pc
3570	05662	SPRING WASHER B6	6 pc
3580	05628	HEX.HEAD NUT M6	6 pc
3590	05545	SEALING CAP 7/16"UNF	3 pc
3600	05528	UNION NUT 7/16"UNF	3 pc
3999	02279 02280 02281 02282 02283 02284	REFR.MACH.OIL SP46 / 1 LTR.CAN REFR.MACH.OIL SP46 / 5 LTR.CAN REFR.MACH.OIL SP46 /20 LTR.CAN NOT SHOWN ONLY FOR R22-COMPRESSORS ! REFR.MACH.OIL SE55 / 1 LTR.CAN REFR.MACH.OIL SE55 / 5 LTR.CAN REFR.MACH.OIL SE55 /10 LTR.CAN NOT SHOWN ONLY FOR X-COMPRESSORS !	1 pc 1 pc 1 pc 1 pc 1 pc 1 pc