

Spare part list for SHGZ7/2110-4 L R22 (as of DK 076)

Position	Item No.	Description	Quantity
10	28137 28138 28139 28140 28141 28142 28134 28135 28136	HGZ7/1620-4 R22 HGZ7/1860-4 R22 HGZ7/2110-4 R22 HGZX7/1620-4 R404A/R507 HGZX7/1860-4 R404A/R507 HGZX7/2110-4 R404A/R507 HGZX7/1620-4 R448A/449A HGZX7/1860-4 R448A/449A HGZX7/2110-4 R448A/449A -----	1 pc 1 pc 1 pc 1 pc 1 pc 1 pc 1 pc 1 pc 1 pc
20	60034	REFRIGERANT RECEIVER 35 LTR.	1 pc
22	51302	SEAL RING 25x23x1,5 (f.1 1/4")	1 pc
23	51307	LOCKING SCREW 1/2" NPTF	1 pc
30	70135 70473	AIR-COOLED CONDENSOR UP TO DESIGN KEY 075 COND.NOT AVAILABLE ANYMORE REPLACED BY POS. 30+50+2100, DESIGN KEY 076 AIR-COOLED CONDEN.5RR/60RH/20K AS OF DESIGN KEY 076	1 pc 1 pc
50	03418 52162	BASE ANGLE (PAIR) UP TO DESIGN KEY 075 NOT AVAILABLE ANYMORE/INACTIVE BASE ANGLE (PAIR) AS OF DESIGN KEY 076	1 pc 1 pc
55	52163	STRUT	2 pc
1520	08579	SET-RUBBER PLATE	1 pc
2000		----- ASSEMBLY KITS -----	1 pc
2024	82297	SET-SHUT-OFF VALVE 7/8"/SOLD.	1 pc
2025	81399	SET-SIGHT GLASS	1 pc
2030	82302	SET-O-RINGS	1 pc
2100	80332 82222	SET-VENTILAT.CPL.ø500 230V AC UP TO DESIGN KEY 075 SET-VENTILAT.CPL.ø450 230V AC AS OF DESIGN KEY 076	4 pc 4 pc
2200	08876	SET-ANTI-VIBRATION PADS	1 pc
2300	80440 80442 80446 80448 81781	SET-LIQ.SUBCOOLER UNIT,R22 FOR SHGZ7/1620 R22 SET-LIQ.SUBCOOLER UNIT,R404A FOR SHGZX7/1620 R404A/R507 SET-LIQ.SUBCOOLER UNIT,R22 FOR SHGZ7/1860+2110 R22 SET-LIQ.SUBCOOLER UNIT,R404A FOR SHGZX7/1860+2110 R404A/R507 SET-LIQ.SUBCOOLER UNIT,R448A FOR SHGZX7 R448A/R449A	1 ST 1 ST 1 ST 1 ST 1 ST
2999		----- ACCESSORIES -----	1 pc
3100	81121	SET-OIL SEPARATOR OS-42FL	1 pc
3110	03454	BRACKET F.OIL SEPARATOR	1 pc
3300	81114 08612	SET-SAFETY VALVE (28BAR) FOR GVN REFRIGERANT RECEIVER SET-SAFETY VALVE (28BAR) NOT AVAILABLE ANYMORE/INACTIVE FOR BWB REFRIGERANT RECEIVER	1 pc 1 pc
3400	81122	SET-HIGH-PRESS./SAFETY/GUARD +LOW PRESSURE CONTROLLER	1 pc

3999	02524 02525	OIL BOCKLub A46 / 1 LTR.CAN OIL BOCKLub A46 / 5 LTR.CAN NOT SHOWN	1 pc 1 pc
	02520 02521 02522	ONLY FOR R22-COMPRESSORS ! OIL BOCKLub E55 / 1 LTR.CAN OIL BOCKLub E55 / 5 LTR.CAN OIL BOCKLub E55 / 10 LTR.CAN NOT SHOWN ONLY FOR X-COMPRESSORS !	1 pc 1 pc 1 pc